


IFX 50/100/200



aquamantaTM
the experts in aquatic technology



***Instruction
Manual***

Contents, Inhalt, Contenu, Inhoud

ENGLISH

Technical Information	4	Maintenance	10-11
Replacement Parts	4	Troubleshooting	12
Important Safeguards	5	Guarantee	13
Overview	6-7		
Setup Instructions	8-9		

DEUTSCH

Technische Spezifikationen	14	Pflege	20-21
Ersatzteile und Filtermedien	14	Problembehandlung	22
Wichtige Sicherheitshinweise	15	Garantie	23
Übersicht	16-17		
Aufbauanleitung	18-19		

FRANCOIS

Spécifications Techniques	24	Entretien	30-31
Pièces de rechange et supports de filtration	24	Dépannage	32
Précautions importantes	25	Garantie	33
Aperçu	26-27		
Instructions d'installation	28-29		

NEDERLANDS

Technical Specificaties	34	Onderhoud	40-41
Vervangende onderdelen	34	Problemen oplossen	42
Belangrijke voorzorgsmaatregelen	35	Garantie	43
Overzicht	36-37		
Vorbereiding Instructies	38-39		

Contenido, Índice, Contenuti, 目录

Información Técnica	44	Mantenimiento	50-51
Partes de repuesto & Medios de filtración	44	Solución de Problemas	52
Medidas de precaución	45	Garantía	53
Descripción General	46-47		
Instrucciones de Configuración	48-49		

ESPAÑOL

Informações Técnicas	54	Manutenção	60-61
Partes de Repuesto	54	Solução de Problemas	62
Precauções Importantes	55	Garantia	63
Visão geral	56-57		
Instruções de preparação	58-59		

PORTUGUÊS

Informazioni Tecniche	64	Manutenzione	70-71
Sostituzione di Componenti	64	Ricerca dei guasti	72
Precauzioni Importanti	65	Garanzia	73
Panoramica	66-67		
Istruzioni di montaggio	68-69		

ITALIANO

参数规格	74	维修保养	80-81
重要保障措施	74	辨别故障/异常情况的处理方法	82
部件	75	保修	83
滤材安装示意图	76-77		
过滤器安装示意图	78-79		

中文

Technical Information

MODEL:	IFX 50	IFX 100	IFX 200
MAX. AQUARIUM VOLUME:	50L	100L	200L
MAX FLOW RATE:	200L/hr	600L/hr	1000L/hr
WATTAGE:	2.6W	7.1W	10.8W
NUMBER OF MEDIA CHAMBERS:	2	2	3

Replacement Parts

Use only AquaManta Genuine Spare Parts. See your local AquaManta dealer and look for the number listed below for the spare part you require. Alternatively you will find these numbers on the silver label located on the product.


MODEL:	IFX 50	IFX 100	IFX 200
IMPELLER:	002i	001i	002i
15ppi SPONGE PAD:	003w	001w	003w
PHOSPAD:	007s	003s	007s
CARBON MODULE:	005s	001s	005s

- Before operating the appliance, please read this manual carefully and keep it properly for future reference.
- Follow the instructions and the “important safeguards” in this manual before use.
- Please be aware of the guarantee conditions which are found at the end of this section of the instruction booklet. This product is shipped to you in a factory sealed carton. Should the product malfunction in any way or if the unit is damaged and requires replacement, contact the retailer where the product was purchased for inspection.
- Do not discard packing material until the product has been assembled.

Important Safeguards


To guard against injury, basic safety precautions should be observed, including the following:

1. Read and follow all safety instructions and important notices in these instructions as well as on the product itself.
2. This appliance is not intended for use by children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
3. To avoid possible electric shocks, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations do not attempt repairs yourself. Return the appliance to an authorised service facility for service or discard the appliance.
 - a. If the appliance or any electrical component of the appliance (non-immersible equipment only) falls into the water or gets wet, do not reach for it. Unplug it and then retrieve it.
 - b. If the appliance shows any sign of abnormal water leakage, immediately unplug it from the power source.
 - c. Carefully examine the appliance after installation. It should not be plugged in if there is water on parts which are not intended to be wet.
 - d. Do not operate the appliance if it has a damaged cord or plug, or if it is malfunctioning, or dropped or damaged in any manner.
4. A “drip loop” (see graphic) should be arranged for each cable connecting an aquarium to a power supply. The drip loop is the part of the cable below the level of the power supply. It prevents water travelling down the cable and coming into contact with the power supply. If the plug or the socket does get wet, do not unplug the appliance. Disconnect the fuse or circuit breaker that supplies the power to the appliance, then unplug and examine for presence of water in the socket.
5. Always unplug the appliance from the electrical outlet when not in use, before putting on or taking off parts, before any type of maintenance or cleaning.
6. Never yank the cable to pull it from the socket. Pull the plug carefully to disconnect.
7. Do not use the appliance for reasons other than the intended use. The use of attachments that are not recommended or sold by the manufacturer may cause the product to be unsafe. This is not recommended.
8. Do not install or store the appliance where it will be exposed to weather or temperatures below freezing.
9. Make sure any component mounted on a tank is securely installed before operating it.
10. Ensure input voltage is the same voltage as your local power supply.
11. If an extension cable is used it should have the proper rating. Care should be taken to arrange the cord so that it will not be tripped or pulled.
12. A G.F.C.I (Ground fault circuit interrupter) & surge protector is recommended for all electrical appliances.
13. Ensure your hands are dry when turning the power switch on/off and when inserting/removing the power cable from the socket.
14. If you are in any doubt about the electrical installation or safety of this product you must consult a qualified electrician.



Know Your Filter

Spray Bar and elbow




IFX 50


IFX 100

IFX 200


Media Container 1




Media Container 2



Media Container 3
(only model 200)



Pump Chamber





	15ppi Sponge
	Phosphate Sponge
	Carbon Module

Installation

1. Open the filter unit
2. Take the filter apart exposing media containers
3. Remove filter media from media container and rinse in tap water to remove excess dust. Rinse the inside of the media container in tap water too. **DO NOT USE ANY SOAPS OR DETERGENTS.**
4. Once all filter media and media containers have been washed insert all the filter media back into the media container in the correct order
5. Connect the elbow and spray bar to the filter for a more dispersed flow.
6. Attach the filter inside the aquarium in the desired location. Ensure the filter is not resting on the substrate nor is it above the water level (straight outlet and spray bar may be above water level).
7. Plug filter into the power outlet and switch on.

Accessing the impeller



Maintenance

1. Unplug filter from power outlet and remove from aquarium. Take the filter to a sink.
2. Remove the cartridge cap allowing access to the first media chamber.
3. Remove the sponges and rinse thoroughly in aquarium water. It is important not to wash the sponge too thoroughly and never wash it in tap water. Sponges should be replaced when there is noticeable deterioration. Phosphate Sponges should be replaced every 4-6 weeks.
4. Remove the carbon module. These should be lightly rinsed in aquarium water. The carbon cartridge should be replaced every 6-8 weeks.
5. Following the diagram in page 7, remove the impeller from the pump. Wash the impeller thoroughly every 4-6 weeks and clean the impeller chamber (inside the motor) using an Aqua One double ended pipe brush (sold separately).
6. Reassemble the filter and place the filter back inside the aquarium.
7. Ensure your hand is not wet and there is no water on the electrical plug. Plug the filter into the power outlet and switch on.

Troubleshooting

FILTER WILL NOT START

1. Check that the power outlet is switched on and the filter is plugged in.
2. Check that the impeller and shaft are in good condition. remove pump from pump chamber and turn the power on to check if the impeller is running.

Disposal of used Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



This symbol on the product or on its packaging indicates that the product must not be disposed of with normal household waste. Instead, it is your responsibility to dispose of your waste equipment by arranging to return it to a designated collection point for the recycling of waste electrical and electronic equipment. By separating and recycling your waste equipment at the time of disposal you will help to conserve natural resources and ensure that the equipment is recycled in a manner that protects human health and the environment. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you have purchased the product.

Guarantee

The additional 1 Year Extended Guarantee applies when you REGISTER online with AquaManta. Register your Extended Guarantee at www.aquamanta.co.uk

About this Guarantee

The Manufacturer or Distributor, of AquaManta goods, is collectively known herein as “AquaManta”. Please refer to contact details for AquaManta below or on the applicable AquaManta website. Any product that is covered by its own Guarantee (as enclosed with the product) is subject to the conditions of that Guarantee.

The benefits given to the purchaser, under Guarantee, are in addition to all other statutory rights and remedies which the purchaser has in respect of goods under legislation in the applicable country of purchase. This Guarantee shall not affect any such rights and should be read subject to such legislation.

1.0. Terms and Conditions of Guarantee.

1.1. AquaManta warrants to the purchaser, for 2 Years from date of original purchase, to repair or replace goods where fault is found due to defective materials or faulty workmanship and where goods do not operate in accordance with the instructions.

1.2. All claims for repair or replacement must be made at place of purchase.

1.3. The original and dated Proof of Purchase (receipt) must be supplied with all goods claims. Please also provide this Guarantee where possible.

1.4. The Guarantee covers the Aquarium against gluing breakdown resulting in leakage.

1.5. All goods subject to claim under Guarantee should be prepared for transportation in the original packaging or other comparable packaging which offers the same degree of protection.

1.6. Where goods are repaired or replaced under Guarantee, these goods are Guaranteed for the remainder of either the original Guarantee or Extended Guarantee period.

1.7. Where claims on inspection reveal goods are in normal working order, AquaManta will request reimbursement of all reasonable costs incurred.

2.0. Other Terms and Conditions – Extended Guarantee

2.1. The Extended Guarantee period is for an additional 1 Year and commences on expiration of the standard guarantee period.

2.2. Application for Extended Guarantee is FREE of any registration cost to the purchaser on completion of the Extended Guarantee questionnaire which is found on the applicable AquaManta website (refer below).

2.3. Upon receipt and acceptance of the questionnaire, AquaManta will forward (by way of email) a Certificate of Extended Guarantee to the purchaser.

2.4. For more information on how we collect, hold, use and disclose personal information provided to us, please refer to our Privacy Statement on the AquaManta websites or write to our Privacy Officer, in your country of purchase.

2.5. Where AquaManta determines goods are being used in a manner contrary to the instructions, specifications or this Guarantee, AquaManta reserves the right to terminate Extended Guarantee for such goods and will provide written notice to the purchaser.

3.0. Exclusions and Limitations

Where permitted by local law, the following exclusions and limitations apply in regard to Guarantee:

3.1. Goods claims where fault is due to, but not limited by a) misuse b) neglect c) abuse d) fire or flood e) normal wear and tear f) accidental breakage g) Acts of God h) mains voltage fluctuation or supply problems i) connection to any voltage other than what is stated on the rating plate j) modification or tampering to electrical cord or plug, k) vermin, insects or foreign object l) liquid spillage or submersion of goods not designed to sustain such use or duress.

3.2. Where inspections reveal goods are in normal working order including where noise or vibration is consistent with normal goods operation.

3.3. Attempted repairs or modifications by unauthorised persons, including but not limited to the drilling of holes in the aquarium glass by unauthorised persons.

3.4. Where the goods factory rating plate has been removed, altered, damaged or is rendered illegible.

3.5. Where goods are not installed, operated or maintained in accordance with AquaManta’s goods instructions, specifications or this Guarantee.

3.6. Replacement or repair of worn consumables or replacement of lost goods, parts or components.

3.7. Costs associated with goods transportation, removal, installation, postage or cost of insurance.

3.8. Any damage incurred whilst installing, transporting or moving the goods.

3.9. Subject to certain local statutory rights and obligations to the contrary, and this guarantee shall not affect those rights or obligations, where, to the full extent permitted by law: 1. all express and implied warranties and conditions under statute or general law, are expressly excluded and AquaManta, where permitted, will limit liability as follows and at AquaManta’s option to: in regard to goods either a) the replacement of goods or supply of equivalent goods b) the repair of goods or the cost of replacing the goods or of acquiring equivalent goods OR in regard to services either c) the re-supply of services d) the cost to re-supply services.

2. AquaManta will not be liable for any loss or damage, including consequential loss or damage either directly or indirectly, or for any incidental expenses, of any kind, and in any way whatsoever.


(1) Consumables include items such as filter media/cartridges, impellers and shafts.

The additional 1 Year Extended Guarantee applies when you REGISTER online with AquaManta. Register your Extended Guarantee at www.aquamanta.co.uk

AquaManta can be contacted at:

Kong's (UK) Limited, Unit 10 Oriana Way, Nursling Industrial Estate
Southampton, SO16 0YU, United Kingdom

Local distributors of AquaManta products can be found at www.aquamanta.co.uk



aquamantaTM
the experts in aquatic technology

Manufactured in China
AquaMantra and Kong's are registered
trademarks of Kong's (Aust.) Pty Limited.
www.aquamanta.com.au



Instruction version: 05/05/2011

